

FIG. 1




FIG.2





FIG.3

FIG.4




FIG.5(a)




FIG.5(b)




FIG.6(a)




FIG.6(b)





FIG.7



00000000000000000000000000000000

FIG.8




FIG.9




FIG. 10




FIG.11





FIG.12

FIG.13




FIG.14

NAME OF SIGNAL	ABBREVIATION	DIRECTION OF SIGNAL
PRINTER POWER READY	/PPRDY	CONTROLLER → PRINTER
CONTROLLER POWER READY	/CPRDY	CONTROLLER → PRINTER
READY	/RDY	CONTROLLER ← PRINTER
PRINTING	/PRINT	CONTROLLER ← PRINTER
TOP OF PAGE	/TOP	CONTROLLER → PRINTER
LINE SYNCHRONISM	/LSYNC	CONTROLLER ← PRINTER
VIDEO CLOCK	/VCLK	CONTROLLER → PRINTER
IMAGE ENABLE	/VDOEN	CONTROLLER ← PRINTER
IMAGE	/VDO	CONTROLLER → PRINTER
CONTROLLER CLOCK	/CCLK	CONTROLLER → PRINTER
COMMAND BUSY	/CBSY	CONTROLLER → PRINTER
COMMAND	/CMD	CONTROLLER → PRINTER
STATUS BUSY	/SBSY	CONTROLLER → PRINTER
STATUS	/STS	CONTROLLER ← PRINTER
PRINTER POWER READY	/PFED	CONTROLLER ← PRINTER
SPEED CHANGE	/SPCCHG	CONTROLLER ← PRINTER
SHEET DELIVERY	/PDLV	CONTROLLER ← PRINTER
TOP OF SHEET	/TOPR	CONTROLLER ← PRINTER
NOTIFICATION OF CHANGE IN STATE	/CCRT	CONTROLLER ← PRINTER

FIG.15




FIG.16




FIG.17




FIG.18




FIG.19




FIG.20




FIG.21




FIG.22

